



* WR232Y10 used in conjunction with WR232Y09 to connect our serial CFA632 or CFA634 displays to a standard 9-pin RS232 connection on a PC, or USB232A conventen.